Application List - Version 9.4.1 - Renault

Icons Legend

Existing Functionality

Under Development

Funcionality does not apply

ABS / ABR				
System	**DTCs**	**Parameters**	**Actuators**	**Configurations**
ABS 8.0 V3 (MEGANE II)				
Configurations				
After-Sales Operation Date				
Speedo Index				
Write of VIN				
ABS 8.0 x06/65/76 v2				
Configurations				
Speedo Index				
Vehicle Parameter				
Write of VIN				
ABS 8.0 X85 VDIAG 15 (CLIO III)				
ABS BOSCH 5.3 (2XX.5)				
Configurations				
Speed Index Programming				
ABS BOSCH 8.0				
Configurations				
Bleed Hydraulic Unit And Braking Circuits				
PostSale Repair Date Modification				
Speedo Index				
Write of VIN				
ABS BOSCH 8.0 (MODUS)				
ABS EBC 430 TRW				
Configurations				
PostSale Repair Date Modification				
Speedo Index				
ABS ESP D66 Bosch_5.7				
ABS ESP-0000-10				
Configurations				
Auto stop lights illumination authorization				
Brake pressure offset sensor				
Chassis wear programming				
GearBox Type				
Hydraulic brake compensation				
PostSale Repair Date Modification				
Prevention of stop light auto illumination				
Speedo Index				
Steering wheel angle offset sensor				
Transverse acceleration offset sensor				
Vehicle parameters				
Write of VIN				
ABS MK60 x74				
Configurations				
ABS / ESP Calibration Programming				
After Market Repair Date				
Braking Definition				

Engine Torque Index

GearBox Type

Speedo Index

Vehicle Parameter

Write of VIN

ABS TEVES 30X5				
ABS TEVES 3XX5				

Configurations

Speed Index

ESP MK60 x74				

Configurations

ABS / ESP Calibration Programming
After Market Repair Date

Braking Definition

GearBox Type

Remote Control Cruise Control
Serial Number of the Vehicle - VIN code

Speed Index

Steering Wheel Angle Sensor

Vehicle Parameter

ADDITIONAL HEATER

System	DTCs	Parameters	Actuators	Configurations
ADD HEATER_ X74_X73				

Configurations

Erase Incorrect Cranking Counter
Erase Overheating Counter

AIRBAG / PRETENSIONER

System	DTCs	Parameters	Actuators	Configurations
AIRBAG AB9 X77 (MODUS)				

Configurations

After-Sales Operation Date

Airbags Locking

Airbags Unlocking

Curtain Side Airbag, Driver´s Side
Curtain Side Airbag, Passenger Side
Driver Lap Strap Pretensioner

Driver´s Lateral Sensor

Driver´s Seat buckle Sensor
Driver's Front Airbag Circuit 1
Driver's Front Airbag Circuit 2
Driver's Seat Position Sensor
Front Seat Belt Retractors
Front Thorax Side Air Bag , Passenger Side
Front Thorax Side Air Bag, Driver´s Side
Passenger Airbag Locking Mode
Passenger Lap Strap Pretensioner
Passenger Presence Detection Sensor
Passenger´s Lateral Sensor
Passenger´s Seat Buckle Sensor
Passenger's Frontal Airbag Circuit 1
Passenger's Frontal Airbag Circuit 2

Rear Inertia Reels

Vehicle Type

Write of VIN

AIRBAG AB9 X85 (CLIO III)				

Configurations

After-Sales Operation Date

Airbags Locking

Airbags Unlocking

Curtain Side Airbag, Driver´s Side
Curtain Side Airbag, Passenger Side
Driver´s Lap Strap/Seat Airbag

Driver´s Lateral Sensor

Driver´s Seat buckle Sensor

Driver´s Seat Sensor

Driver's Front Airbag Circuit 1
Driver's Front Airbag Circuit 2
Front Seat Belt Retractors

Front Thorax Side Air Bag , Passenger Side
Front Thorax Side Air Bag, Driver´s Side
Passenger Presence Detection Sensor
Passenger´s Lap Strap/Seat Airbag
Passenger´s Lateral Sensor
Passenger´s Seat Buckle Sensor
Passenger's Airbag Disable Mode
Passenger's Frontal Airbag Circuit 1
Passenger's Frontal Airbag Circuit 2
Rear Inertia Reels
Vehicle Type
Write of VIN

AIRBAG ACU3 Avantime

Configurations

Curtain Side Airbag, Driver´s Side
Curtain Side Airbag, Passenger Side
Driver Inertia Reel
Driver´s Lateral Sensor
Driver's Front Airbag
Driver's Pretensioner
Front Thorax Side Airbag Driver side
Front Thorax side Airbag Passenger Side
Ignition Module Configuration
Locking - Unlocking
Passenger Inertia Reel
Passenger´s Lateral Sensor
Passenger's Frontal Airbag Circuit 1
Passenger's Frontal Airbag Circuit 2
Passenger's Pretensioner
Side Sensors Configuration
Vehicle Type
Write of VIN

AIRBAG ACU3 MK2 X70

Configurations

After-Sales Operation Date
Airbags Locking
Airbags Unlocking
Vehicle Type
Write of VIN

AIRBAG ACU3 MK2 X76

Configurations

Configuration of System Components
Driver´s Lateral Sensor
Driver's Front Airbag
Driver's Front Airbag
Driver's Front Buckle Pretensioner
Driver's Pretensioner
Front Passenger(s) Pretensioner(s)
Front Thorax Side Air Bag , Passenger Side
Front Thorax Side Air Bag, Driver´s Side
Front Thorax Side Airbag Driver side
Front Thorax side Airbag Passenger Side
Ignition Module Configuration
Impact Information Connection
Locking - Unlocking
Passenger Airbag Locking by Key
Passenger´s Lateral Sensor
Passenger's Front Airbag
Passenger's Front Airbag
Passenger's Front Buckle Pretensioner
Side Sensors Configuration
Vehicle Type
Write of VIN

AIRBAG ACU3 Renault X83 vdiag20

Configurations

Driver Side Front Curtain Airbag
Driver Side Rear Curtain Airbag
Driver's Front Airbag
Driver's Front Airbag
Driver's Pretensioner

Driver's Pretensioner

Front Passenger(s) Pretensioner(s)
Front Passenger(s) Pretensioner(s)
Front Passenger(s) Pretensioner(s)
Front Thorax Side Air Bag , Passenger Side
Front Thorax Side Air Bag, Driver´s Side
Front Thorax Side Airbag Driver side
Front Thorax side Airbag Passenger Side
Igniters In Series Configuration
Ignition Module Configuration

Lock Computer

Passenger Side Front Curtain Airbag
Passenger Side Rear Curtain Airbag
Passenger's Front Airbag
Passenger's Front Airbag
PostSale Repair Date Modification
Pretensioner Row 1 Driver´s Side
Pretensioner Row 1 Driver´s Side
Pretensioner Row 1 Passenger´s Side
Pretensioner Row 1 Passenger´s Side
Pretensioner Row 2 Driver´s Side
Pretensioner Row 2 Driver´s Side
Pretensioner Row 2 Passenger´s Side
Pretensioner Row 2 Passenger´s Side
Side On Which Steering Wheel Fitted

Unlock Computer

Write of VIN

AIRBAG ACU4 (MEGANE II)

Configurations

After-Sales Operation Date

Airbags Locking

Airbags Unlocking

Curtain Side Airbag, Driver´s Side
Curtain Side Airbag, Passenger Side
Driver´s Lap Strap/Seat Airbag

Driver´s Lateral Sensor

Driver´s Seat buckle Sensor
Driver's Front Airbag Circuit 1
Driver's Front Airbag Circuit 2
Driver's Seat Position Sensor
Front Buckle Pretensiometers
Front Thorax Side Airbag Driver side
Front Thorax side Airbag Passenger Side
Passenger Airbag Locking Mode
Passenger´s Lap Strap/Seat Airbag
Passenger´s Lateral Sensor
Passenger's Frontal Airbag Circuit 1
Passenger's Frontal Airbag Circuit 2

Rear Inertia Reels

Rear Thorax side Airbag Driver Side
Rear Thorax Side Airbag Passenger Side

Vehicle Type

Write of VIN

AIRBAG ACU4 MK2 (MEGANE II)

Configurations

After-Sales Operation Date

Airbags Locking

Airbags Unlocking

Curtain Side Airbag, Driver´s Side
Curtain Side Airbag, Passenger Side
Driver Side Rear Frontal Airbag
Driver´s Lap Strap/Seat Airbag

Driver´s Lateral Sensor

Driver´s Seat buckle Sensor

Driver´s Seat Sensor

Driver´s Side Rear Strap Sensor
Driver's Front Airbag Circuit 1
Driver's Front Airbag Circuit 2
Front Buckle Pretensiometers
Front Thorax Side Airbag Driver side
Front Thorax side Airbag Passenger Side
Passenger Presence Detection Sensor
Passenger Side Rear Frontal Airbag
Passenger Side Rear Strap Sensor
Passenger´s Lap Strap/Seat Airbag
Passenger´s Lateral Sensor
Passenger´s Seat Buckle Sensor
Passenger's Airbag Disable Mode
Passenger's Frontal Airbag Circuit 1
Passenger's Frontal Airbag Circuit 2

Rear Inertia Reels

Rear Thorax side Airbag Driver Side
Rear Thorax Side Airbag Passenger Side
Side n Which Steering Wheel Fitted

Vehicle Type

Write of VIN

AIRBAG AUTOLIV AC4 ph1 version X

Configurations

Airbags Locking

Airbags Unlocking

PostSale Repair Date Modification

AIRBAG AUTOLIV AC4 ph2

Configurations

Airbags Locking

Airbags Unlocking

Passenger's Frontal Airbag Locking
Passenger's Frontal Airbag Unlocking
PostSale Repair Date Modification

AIRBAG AUTOLIV AC6 ph1 version 01

Configurations

Airbags Locking

Airbags Unlocking

PostSale Repair Date Modification

AIRBAG AUTOLIV AC6 ph2

Configurations

Airbags Locking

Airbags Unlocking

Passenger's Frontal Airbag Locking
Passenger's Frontal Airbag Unlocking
PostSale Repair Date Modification

AIRBAG AUTOLIV ACU3 x64 - x06

Configurations

After Market Repair Date
Configuration of System Components
Curtain Side Air Bag, Driver`s Side
Curtain Side Air Bag, Passenger Side
Curtain Side Airbag, Driver´s Side
Curtain Side Airbag, Passenger Side

Driver´s Lateral Sensor

Driver's Front Airbag

Driver's Front Airbag

Front Pretensioners

Front Pretensioners Circuit
Front Thorax Side Air Bag , Passenger Side
Front Thorax Side Air Bag, Driver´s Side
Front Thorax Side Airbag Driver side
Front Thorax side Airbag Passenger Side
Ignition Module Configuration
Impact Information Connection

ISOFIX Function

Lock / Unlock Passenger´s Front Air Bag

Locking - Unlocking

Passenger Air Bag Locking Type
Passenger Airbag Locking by Key
Passenger´s Lateral Sensor
Passenger's Front Airbag
Passenger's Front Airbag
Rear Inertia Reels / Pretensioners
Rear Inertial Reel/Pretensioner Circuits
Side Sensors Configuration

Vehicle Type

AIRBAG AUTOLIV ACU3 X83

Configurations

After Market Repair Date

Driver´s Lateral Sensor

Driver's Front Airbag

Driver's Front Airbag

Driver's Pretensioner

Driver's Pretensioner

Front Passenger(s) Pretensioner(s)
Front Passenger(s) Pretensioner(s)
Front Passenger(s) Pretensioner(s)
Front Thorax Side Air Bag , Passenger Side
Front Thorax Side Air Bag, Driver´s Side
Front Thorax Side Airbag Driver side
Front Thorax side Airbag Passenger Side
Igniters In Series Configuration
Ignition Module Configuration

Locking - Unlocking

Passenger´s Lateral Sensor
Passenger's Front Airbag
Passenger's Front Airbag
Pretensioner Row 1 Driver´s Side
Pretensioner Row 1 Driver´s Side
Pretensioner Row 1 Passenger´s Side
Pretensioner Row 1 Passenger´s Side
Pretensioner Row 2 Driver´s Side
Pretensioner Row 2 Driver´s Side
Pretensioner Row 2 Passenger´s Side
Pretensioner Row 2 Passenger´s Side
Serial Number of the Vehicle - VIN code
Side Sensors Configuration

Vehicle Type

AIRBAG AUTOLIV EC5

Configurations

Airbags Locking

Airbags Unlocking

PostSale Repair Date Modification

AIRBAG BOSCH AB 7.0

Configurations

Airbags Locking

Airbags Unlocking

PostSale Repair Date Modification

AIRBAG BOSCH AB 8.0

Configurations

Airbags Locking

Airbags Unlocking

Passenger's Frontal Airbag Locking
Passenger's Frontal Airbag Unlocking
PostSale Repair Date Modification

AIRBAG BOSCH AB 8.1

Configurations

Airbags Locking

Airbags Unlocking

Passenger's Frontal Airbag Locking
Passenger's Frontal Airbag Unlocking
PostSale Repair Date Modification
Side Sensors Configuration Setup

AIRBAG BOSCH AB 8.2 X65 Ph2

Configurations

Airbags Locking

Airbags Unlocking

Driver Pretensioner Circuit Resistance
Driver's Front Airbag Circuit 1
Driver's Front Airbag Circuit 2
Driver's Seat Position Sensor
Driver's Side Head Lateral Airbag

Driver's Side Rear Reel

Driver's Side Sensor

Driver's Side Thorax Lateral Airbag
Passenger Pretensioner Circuit Resistance
Passenger's Airbag Disable Mode
Passenger's Frontal Airbag Circuit 1
Passenger's Frontal Airbag Circuit 2
Passenger's Side Head Lateral Airbag
Passenger's Side Rear Reel
Passenger's Side Thorax Lateral Airbag
PostSale Repair Date Modification

Side Passenger Sensor

AIRBAG BX7374 VD24-315-24

Configurations

Configuration of System Components

Curtain Side Airbag, Driver´s Side
Curtain Side Airbag, Passenger Side
Driver Lap Strap Pretensioner
Driver Side Loop Pretensioners

Driver´s Seat Sensor

Driver's Front Airbag Circuit 1
Driver's Front Airbag Circuit 2
Front Seat Inertia Reel Locking
Front Thorax Side Airbag Driver side
Front Thorax side Airbag Passenger Side
Ignition Module Configuration

Lock Computer

Passenger Airbag Locking by Key
Passenger Lap Strap Pretensioner
Passenger Side Loop Pretensioners
Passenger's Frontal Airbag Circuit 1
Passenger's Frontal Airbag Circuit 2
PostSale Repair Date Modification
Rear Thorax side Airbag Driver Side
Rear Thorax Side Airbag Passenger Side
Side On Which Steering Wheel Fitted
Side On Which Steering Wheel Fitted

Unlock Computer

Vehicle Type

Write of VIN

AIRBAG BX7374 VD2C-315-2C

Configurations

Configuration of System Components
Curtain Side Airbag, Driver´s Side
Curtain Side Airbag, Passenger Side
Driver Lap Strap Pretensioner
Driver Side Loop Pretensioners

Driver´s Seat Sensor

Driver's Front Airbag Circuit 1
Driver's Front Airbag Circuit 2
Front Seat Inertia Reel Locking
Front Thorax Side Airbag Driver side
Front Thorax side Airbag Passenger Side
Ignition Module Configuration

Lock Computer

Passenger Airbag Locking by Key
Passenger Lap Strap Pretensioner
Passenger Side Loop Pretensioners
Passenger's Frontal Airbag Circuit 1
Passenger's Frontal Airbag Circuit 2
PostSale Repair Date Modification
Rear Thorax side Airbag Driver Side
Rear Thorax Side Airbag Passenger Side
Side On Which Steering Wheel Fitted
Side On Which Steering Wheel Fitted

Unlock Computer

Vehicle Type

Write of VIN

AIRBAG MATRA SDM (ESPACE)

Configurations

After Market Repair Date
Fuel Pump Cut Off Configuration

Locking - Unlocking

Side Airbag

AIRBAG-315-0C

Configurations

Configuration of System Components
Curtain Side Airbag, Driver´s Side
Curtain Side Airbag, Passenger Side
Driver Lap Strap Pretensioner
Driver Side Loop Pretensioners

Driver´s Lateral Sensor

Driver´s Seat Sensor

Driver's Front Airbag Circuit 1
Driver's Front Airbag Circuit 2
Front Thorax Side Airbag Driver side
Front Thorax side Airbag Passenger Side
Ignition Module Configuration

Lock Computer

Passenger Airbag Locking by Key
Passenger Lap Strap Pretensioner
Passenger Side Loop Pretensioners
Passenger´s Lateral Sensor
Passenger's Frontal Airbag Circuit 1

Passenger's Frontal Airbag Circuit 2
Rear Thorax side Airbag Driver Side
Rear Thorax Side Airbag Passenger Side
Side Sensors Configuration

Unlock Computer

Vehicle Type

Write of VIN

AIRBAG-315-14				

Configurations

After Market Repair Date
Configuration of System Components
Curtain Side Air Bag, Driver`s Side
Curtain Side Air Bag, Passenger Side
Curtain Side Airbag, Driver´s Side
Curtain Side Airbag, Passenger Side
Driver Lap Strap Pretensioner
Driver Lap Strap Pretensioner
Driver Side Loop Pretensioners
Driver Side Loop Pretensioners

Driver´s Lateral Sensor

Driver´s Seat Sensor

Driver's Front Airbag Circuit 1
Driver's Front Airbag Circuit 1
Driver's Front Airbag Circuit 2
Driver's Front Airbag Circuit 2
Front Seat Inertia Reel Locking
Front Thorax Side Air Bag , Passenger Side
Front Thorax Side Air Bag, Driver´s Side
Front Thorax Side Airbag Driver side
Front Thorax side Airbag Passenger Side
Ignition Module Configuration

Locking - Unlocking

Passenger Airbag Locking by Key
Passenger Lap Strap Pretensioner
Passenger Lap Strap Pretensioner
Passenger Side Loop Pretensioners
Passenger Side Loop Pretensioners
Passenger´s Lateral Sensor
Passenger's Frontal Airbag Circuit 1
Passenger's Frontal Airbag Circuit 1
Passenger's Frontal Airbag Circuit 2
Passenger's Frontal Airbag Circuit 2
Rear Thorax Side Air Bag , Driver Side
Rear Thorax Side Air Bag , Passenger Side
Rear Thorax side Airbag Driver Side
Rear Thorax Side Airbag Passenger Side
Serial Number of the Vehicle - VIN code
Side Sensors Configuration

Vehicle Type

AIRBAG-315-2D				

Configurations

Configuration of System Components
Driver Lap Strap Pretensioner
Driver Side Front Curtain Airbag
Driver Side Rear Curtain Airbag

Driver´s Seat Sensor

Driver's Front Airbag Circuit 1
Driver's Front Airbag Circuit 2
Front Buckle Pretensiometers
Front Thorax Side Airbag Driver side
Front Thorax side Airbag Passenger Side
Ignition Module Configuration

Lock Computer

Passenger Airbag Locking by Key
Passenger Lap Strap Pretensioner
Passenger Side Front Curtain Airbag
Passenger Side Rear Curtain Airbag
Passenger's Frontal Airbag Circuit 1
Passenger's Frontal Airbag Circuit 2
PostSale Repair Date Modification
Rear Thorax side Airbag Driver Side
Rear Thorax Side Airbag Passenger Side
Side On Which Steering Wheel Fitted
Side On Which Steering Wheel Fitted

Unlock Computer

Vehicle Type

Write of VIN

AUTOMATIC GEARBOX

System	DTCs	Parameters	Actuators	Configurations
AUTOMATIC GEARBOX BVR-X70 X83				

Configurations

Clutch Initial Closed Position
Program Clutch Open Position

Programme Slip Point

Programmed Values

Programming Selection / Engaging Zones
Write Date Of Last After Sales Operation

Write of VIN

AUTOMATIC GEARBOX DP0-TA2000-APV				

Configurations

Air Conditioning With Wire Connection
Check Motor Torque by ABS
Converter Lock Up Adaptative

OBD Memory

Selector Lever Locking

Trajectory Control

BVA A 4.2 AUTOMATIC GEARBOX				
CAMBIOS AUTOMATICOS BVA DP0 Ta2000-0000-00				

Configurations

AIR CONDITIONING OUTPUT USE
AIR CONDITIONING WITH WIRE CONNECTION

AUTO-ADAPTIVES

CHECK MOTOR TORQUE BY ABS

CONTACT

CONTROLLED SLIP

Converter Lock Up Adaptative
DECLUTCH WHEN STATIONARY

DIALOGUE IN COUPLE

LINKED TO TURBINE SPEED

OBD Memory

SELECTOR LEVER LOCKING
SELECTOR LEVER LOCKING
TRAJECTORY CONTROL

Write of VIN

DP0 AUTOMATIC GEARBOX				

Configurations

After Market Repair Date

Air Conditioning

Distance Before Next Oil Change

OBD

Pedal Learning

Reset Auto-Adaptive Values
Reset the Oil Aging Counter

ISO M4.2 AUTOMATIC GEARBOX				
ISO M4.3 AUTOMATIC GEARBOX				
SU1 AUTOMATIC GEARBOX 2001				

Configurations

Reset self-adaptation parameters
Serial Number of the Vehicle - VIN code

SU1 AUTOMATIC GEARBOX apv				

Configurations

Reset self-adaptation parameters
Serial Number of the Vehicle - VIN code

ZF LM0 AUTOMATIC GEARBOX				

Configurations

Reset Auto-Adaptive Values

CLIMATRONIC CONTROL

System	DTCs	Parameters	Actuators	Configurations
AIR CONDITIONING BAC-ECO				

Configurations

Coolant Sensor

Evaporator Temperature Sensor
Recycling Flap Auto-Setting

Recycling Motor Timer

Test Configuration

Type Compressor

Type Control

CLIM. REGULEE - 002 - 09

Configurations

Compressor Type

Drive Ratio

Evaporator Temperature Sensor

Heated Windscreen

Type of Power Steering

Vehicle Type

Write of VIN

CLIMATIZACIÓN X65 Régulée

CLIMATIZATION MANUAL-000-08

Configurations

Compressor Type

Compressor Type

Drive Ratio

Drive Ratio

Engine Cooling Fan Signal By Injection

Engine Type

Evaporator Temperature Sensor

Evaporator Temperature Sensor

Write of VIN

CLIMATIZATION REGULEE (MEGANE II)

Configurations

Heating Resistor Type

Vehicle Type

Write of VIN

CLIMATIZATION REGULEE J81 VDIAG 11-0000-11

Configurations

Additional Heating

Air Conditioning Type

Alternator type

Compressor Type

Drive Ratio

Driving Type

Geographical Zone

Heating Resistor Type

Rear Shelves

Write of VIN

CLIMATRONIC X74 X73

Configurations

Compressor Type

Drive Ratio

Evaporator Temperature Sensor

Heater Windscreen Information

Serial Number of the Vehicle - VIN code

Steering Type Configuration

REGULATED CLIMATRONIC J64

Configurations

PostSale Repair Date Modification

REGULATED CLIMATRONIC J66 - D66

Configurations

Avantime (Except F4R)

Avantime (F4R)

Evaporator Sensor

REGULATED CLIMATRONIC X56

REGULATED CLIMATRONIC X74

Configurations

Additional heating

Compressor Type

Drive Ratio

Evaporator Temperature Sensor
Heater Windscreen Information
Serial Number of the Vehicle - VIN code
Steering Type Configuration

Vehicle Type

DISCHARGE LAMP

System	DTCs	Parameters	Actuators	Configurations
COSLAD P52 J66 (Espace)				
COSLAD X65				

Configurations

Engine Type

DISCHARGE LAMP (CAN)				
DISCHARGUE LAMP-000-45				

Configurations

Automatic Fold - Down Headlights

Cornering Lights

Dipped Headlights Raise

Dynamic Correction

Signature

SYSTEM INITIALISATION

Vehicle Type

Write of VIN

LAD J84-0101-05				

Configurations

Serial Number of the Vehicle - VIN code

Vehicle Type

ELECTRICAL SUPERVISOR

System	DTCs	Parameters	Actuators	Configurations
SUPER x76 soft B2. YY RNUR				

Configurations

100 Ah Traction Battery
Maintennace Charge Request

Range Extension

Reset Direction Of Movement
Reset Full Load Accelerator Potentiometer
Reset No Load Accelerator Potenciometer

ELECTRONIC CLUTCH

System	DTCs	Parameters	Actuators	Configurations
ELECTRONIC CLUTCH X06				

Configurations

After-Sales Operation Date
Clutch Cylinder and Solenoid Valves Zero Position Memorization

ELECTRONIC DASHBOARD

System	DTCs	Parameters	Actuators	Configurations
ELECTRONIC DASHBOARD X56				

Configurations

5 cylinder ECU Programming
ECU Programming with 4 Cylinders
ECU Programming with 6 Cylinders
ECU Programming with Immobilizer Type 1
ECU Programming with Immobilizer Type 2

INSTRUMENT PANEL (MODUS)				
INSTRUMENT PANEL BII 3.9 (J66)				

Configurations

Hazard Lamps Recall On TRF

INSTRUMENT PANEL X74 vdiag 16				

Configurations

Distance Before Next Oil Change

Distance Regulator

Engine / Gearbox Type

Language Version

Seat Belt not Fastened Buzzer
Serial Number of the Vehicle - VIN code

Tyre Pressure

Vehicle Type

INSTRUMENT PANEL-001-08 (SCENIC II)				

Configurations

Automatic Handbrake

Consumption Measurement Units
Cruise Control / Speed Limiter

Distance Units

Fuel type

GearBox Type

Language

Oil Change Interval in Miles
Oil Change Interval in Months
Overspeed Function - Arabia

Trajectory Control

Tyre Pressure Monitoring

Vehicle Type

Write of VIN

INSTRUMENT PANEL-4.1-04				

Configurations

Arabian Overspeed

Consumption Measurement Units
Cruise Control / Speed Limiter

Distance Units

Fuel Type

GearBox Type

Language

Oil Change Interval in Miles
Oil Change Interval in Months

Reserve Capacity

Trajectory Control

Tyre Pressure Monitoring

Vehicle Type

Write of VIN

INSTRUMENT PANEL-400-08				

Configurations

Bodywork type

Card/Key

Clock

Consumption Measurement Units
Cruise Control / Speed Limiter

Distance Units

GearBox Type

Language

Lights Automatic Illumination

Odometer Update

Oil Change Interval in Miles
Oil Change Interval in Months
Overspeed Function - Arabia

Particle Filter

Reserve Capacity

Rheostat Prescence

Seat Belt Reminder Buzzer

Tank Capacity

Tyre Pressure Monitoring
Vehicle Speed Signal Transimter

Write of VIN

ELECTRONIC SUSPENSION

System	DTCs	Parameters	Actuators	Configurations

PILOTED SUSPENSION X70				

Configurations

Write Date Of Last After Sales Operation

ENGINE ELECTRONICS (LPG)

System	DTCs	Parameters	Actuators	Configurations
LPG 2000				

ENGINE ELECTRONICS (PETROL/DIESEL)

System	DTCs	Parameters	Actuators	Configurations
BOSCH AS 3.3				
BOSCH EDC 15C - Vdiag 10 X74 Calib1				

Configurations

Air Conditioning

EGR Type

Enter Injectors Calibration Data

Flow Regulation Type

Gear Box Type

Idle speed

Injection Type

Inlet Type

Number of Cylinders

Serial Number of the Vehicle - VIN code

Swirl Flap

Thermoplunger

Type of High Pressure Pump

BOSCH EDC 15C - Vdiag OC X83				

Configurations

Air Conditioning

CAN Bus

EGR Type

Flow Regulation Type

Gear Box Type

Idle Speed Decrease

Idle Speed Increase

Injection Type

Inlet Type

Number of Cylinders

Serial Number of the Vehicle - VIN code

Thermoplunger

BOSCH EDC 15C - VDIAG 0C X70				

Configurations

Air Conditioning

Decrement Idle Speed

Increment of idle speed

Thermoplunger

BOSCH EDC 15C - Vdiag 10 X64 Calib2				

Configurations

Air Conditioning

Idle Speed Decrease

Idle Speed Increase

Serial Number of the Vehicle - VIN code

Thermoplunger

BOSCH EDC 15C - VDIAG 14 - X76 X64				

Configurations

Air Conditioning

Boiler

Boiler

ECU replacement

Enter Injector Codes

Flow Regulation Type

GearBox Type

IMA Programming

Increment - Decrement of Idle Speed
Power Steering Electric Pump Unit
Read Air Conditioning Configuration

Read EGR Type

Read Injection type

Read Inlet Type

Read number of cylinders

Read Swirl Flap Option

Read Thermoplunger Option

Thermoplunger

Write of VIN

BOSCH EDC 16 C3 (MEGANE II)

Configurations

Air Conditioning

ECU replacement

EGR Adaptative

Enter Injector Codes

Erase Programmed Values
Water in Diesel Information

Write of VIN

BOSCH EDC 16 C3 (SCENIC II)

Configurations

Air Conditioning

Enter Injector Codes

Erase Programmed Values

Water in Diesel Sensor

Write of VIN

BOSCH EDC15 VM+ SOFT C2

Configurations

Air Conditioning

Power Steering Electric Pump Unit

Thermoplunger

BOSCH MONOMOTRONIC MA 1.7

Configurations

Air Conditioning

Fuel Injectors

Learned Parameters Reset

BOSCH MOTRONIC M 4.4.2

BOSCH MOTRONIC MP 7.0

Configurations

Injection System Disabling
Injection System Enabling

BOSCH MSA 15 (CD)

Configurations

Air Conditioning

Idle Speed Decrease

Idle Speed Increase

Power Assisted Steering

Thermoplunger

BOSCH MSA 15 soft CA vdiag 04

Configurations

Air Conditioning

Idle Speed Decrease

Idle Speed Increase

Power Assisted Steering
Thermoplunger

DCM 1.2 (CLIO III)

Configurations

ECU replacement
EGR Adaptative
Erase Programmed Values
Injector programming
Lock Injector Control
Pressure Regulation Adaptives
Write of VIN

DDCR (MEGANE II)

Configurations

ECU replacement
EGR Adaptative
Enter Injector Codes
Erase Programmed Values
GearBox Type
Pressure Regulation Adaptives
Write of VIN

DELPHI LVCR

Configurations

Air Conditioning
Air Conditioning
Cruise Control / Speed Limiter
Cruise Control / Speed Limiter
Enter Injectors Calibration Data
Gear Box Type
Gear Box Type
High Pressure Circuit Leak Test
Idle Speed Decrease
Idle Speed Increase
Injection System Disabling
Learned Parameters Reset
Load disablement
Power Steering Electric Pump Unit
Power Steering Electric Pump Unit
Reset Auto-Adaptive Values
Serial Number of the Vehicle - VIN code
Static / Autoconfiguration Test
Thermoplunger
Thermoplunger

DPCN LUCAS

Configurations

Control Unit Programming without Air Conditioner
ECU Programming with Air Conditioner
ECU Programming with Power Steering
ECU Programming without Power Steering
Injection System Disabling
Injection System Enabling

DPCN LUCAS 1+

Configurations

Control Unit Programming without Air Conditioner
ECU Programming with Air Conditioner
ECU Programming with Power Steering
ECU Programming without Power Steering
Injection System Disabling
Injection System Enabling

DPCN LUCAS 1+RC

Configurations

Control Unit Programming without Air Conditioner
ECU Programming with Air Conditioner
ECU Programming with Power Steering
ECU Programming without Power Steering
Injection System Disabling
Injection System Enabling

EMS 3132 E1 VDIAG 15

Configurations

ABS -> Injection Interface
AC Cold Loop in the Injection
Air Conditioning
Brake Switch Normally Open
Camshaft Offset
Downstream Oxygen Sensor
Engine Immobiliser
Fan Control, Engine Running
Fixed Displacement Compressor
Gear Change Warning Light
GearBox Type
Heated Windscreen
OBD Light
Pencil Type Ignition Coil
Programming Reinitialisation
Reduced Flow Fuel Pump
Upstream Oxygen Sensor
Vehicle Speed Connection Type
Write of VIN

EMS 3132 VDIAG 11

Configurations

AC Cold Loop in the Injection
Camshaft Offset
Downstrean Oxygen Sensor
Fan Control, Engine Running
Fixed Displacement Compresor
Gear Change Warning Light
GearBox Type
Heated Windscreen
Injection -> LPG connection
Pencil Type Ignition Coil
Programming Reinitialisation
Read Air Conditioning Configuration
Reduced Fuel Mode Request
Thermoplunger Management
Upstream Oxygen Sensor
Vehicle Speed Connection Via The CAN

INJECTION EDC 15 C - Vdiag 18 VB0 - IMA

Configurations

Decrement Idle Speed
ECU replacement
Enter Injectors Calibration Data
Increment of idle speed

INJECTION EDC 15C - Vd18 VB0-IMA X70ph2

Configurations

Air Conditioning
Decrement Idle Speed
ECU replacement
Enter Injectors Calibration Data
Increment of idle speed
Passenger Compartment Heating Resistor
Van Fast Idle Speed Decrease
Van Fast Idle Speed Increase
Write of VIN

INJECTION EDC 15C - Vd18 VB3 - IMA X70ph1

Configurations

Air Conditioning
Decrement Idle Speed
ECU replacement
EGR Valve Programming
Engine Adaptatives
Enter Injectors Calibration Data
Increment of idle speed
Passenger Compartment Heating Resistor
Van Fast Idle Speed Decrease
Van Fast Idle Speed Increase
Write of VIN

INJECTION EDC 15C - Vdiag 08 - MASTER
INJECTION EDC 15C - Vdiag 19 VB0- IMA
INJECTION EDC15-00 C3-0C

Configurations

Air Conditioning

Air Conditioning

Decrement Idle Speed

GearBox Type

Increment of idle speed

Read Swirl Flap Option

Thermoplunger

Thermoplunger

Write of VIN

INJECTION EDC15-9BC1-10

Configurations

Air Conditioning

Air Conditioning

ECU replacement

Enter Injector Codes

GearBox Type

Increment - Decrement of Idle Speed

Read Swirl Flap Option

Thermoplunger

Thermoplunger

Write of VIN

INJECTION EDC15C - Vdiag 14 VA2 - IMA

Configurations

Air Conditioning

Decrement Idle Speed

ECU replacement

EGR Valve Programming

Engine Adaptatives

Enter Injectors Calibration Data
Increment of idle speed
Passenger Compartment Heating Resistor
Van Fast Idle Speed Decrease
Van Fast Idle Speed Increase

Write of VIN

INJECTION EDC15-VA2-14

Configurations

Air Conditioning

Air Conditioning

ECU replacement

EGR Adaptative

Engine Adaptatives

Enter Injector Codes

GearBox Type

Increment - Decrement of Idle Speed

Read Swirl Flap Option

Thermoplunger

Thermoplunger

Water in Diesel

Write of VIN

INJECTION EDC15-VB2-18

Configurations

Air Conditioning

EGR Adaptative

Engine Adaptatives

Enter Injector Codes

Increment - Decrement of Idle Speed

Thermoplunger

Write of VIN

INJECTION MSA15 soft CD Vdiag 05

Configurations

Air Conditioning

Decrement Idle Speed

Increment of idle speed
Power Assisted Steering

Thermoplunger

INJECTION MSA15 soft CD Vdiag 06

Configurations

Air Conditioning

Decrement Idle Speed

Increment of idle speed
Power Assisted Steering

Thermoplunger

INJECTION MSA15 soft CD-CE Vdiag 04

Configurations

Air Conditioning

Decrement Idle Speed

Increment of idle speed
Power Assisted Steering

Thermoplunger

INJECTION SIRIUS 35-0E06-04

Configurations

AC Cold Loop in the Injection
Automatic Transmission

Clutch Switch

Idle Speed Decrease

Idle Speed Increase

Misfire of Diagnostic Request
Power Steering Pressure Switch
Programming Reinitialisation
Request for OBD Light by AT

Speed Limitation

Speed Regulation

Write of VIN

LUCAS DCU 3R Vdiag 9

Configurations

Air Conditioner Computer

Air Conditioning

By Engine Management Cold Loop

Cruise Control

Diesel Flow Limitation

EGR Electrovalve

Gear Box Type

Idle Speed

Power Assisted Steering

Preheating Prevention

Stop Pre - Heating Prevention
Vehicle Function Programming

MARELLI 5NR SOFT25 (NON MUX)

Configurations

Catalytic Converter Test

Fuel System Test

Misfiring Test

O2 Sensor Test

MARELLI 5NR X06-X65 SOFT 24-25 OBD

Configurations

Catalytic Converter Test

Fuel System Test

Misfiring Test

O2 Sensor Test
Programming Reinitialisation

MARELLI IAW 5NR

Configurations

Air Conditioning
Learned Parameters Reset
Power Steering

MARELLI IAW 6R

MARELLI IAW G8

MARELLI SFR 200

ME 7.4.6 TWR

Configurations

Programming Reinitialisation

ME 7.4.6 TWR L7X762

Configurations

Programming Reinitialisation

MM EGR X70

MOTRONIC ME 7.4.6

Configurations

Learned Parameters Reset
Write of VIN

MSA15 soft CD-CE Vdiag 05

Configurations

Air Conditioning
Air Conditioning
Atmospheric / Turbo Engine
Cruise Control
Decrement Idle Speed
EGR Type
Flow Regulation Type
GearBox Type
Increment of idle speed
Injection Type
Number of Cylinders
Pas Unit Option
Power Assisted Steering
Thermoplunger
Thermoplunger

S3000 INJECTION

Configurations

AC Cold Loop in the Injection
Cruise Control
Cylinder 1 Recognition
Erase Programmed Values
Lock Injector Control
Speed Limiter
Unlock Injector Control
Upstream Oxygen Sensor
Vehicle Speed Connection Type
Write of VIN

SAGEM S2000

Configurations

Idle Speed Decrease
Idle Speed Increase
Learned Parameters Reset
Serial Number of the Vehicle - VIN code

SAGEM S3000 (MEGANE II)

Configurations

Air conditioner pressure signal

Air Conditioning

Catalytic Converter Diag OBD Sequencer

Cylinder 1 Recognition

Downstream Oxygen Sensor
Erase Programmed Values

GearBox Type

Heating Resistor

Lock Injector Control

Misfire Diag OBD Sequencer

OBD Warning Lamp

Sensors Diag OBD Sequencer

Traction Control

Unlock Injector Control

Upstream Oxygen Sensor
Vehicle Speed Connection Type

Water pump

Wire Closing Brake Switch

Write of VIN

SAGEM S3000 (MODUS)				

Configurations

Air Conditioning

Air Conditioning Pressure Signal Management

Air Pump

Catalytic Converter Diag OBD Sequencer
Controlled Coolant Thermostat

Cylinder 1 Recognition

Downstream Oxygen Sensor
Erase Programmed Values

GearBox Type

Heating Resistor

Lock Injector Control

Misfire Diag OBD Sequencer
OBD Warning Light Management
Sensors Diag OBD Sequencer

Traction Control

Unlock Injector Control

Upstream Oxygen Sensor
Vehicle Speed Connection Type
Wire Closing Brake Switch

Write of VIN

SAGEM TPP EGR				

Configurations

Climatization

Electric Windshield Wiper

SAGEM TPP EGR X56				

Configurations

Air Conditioning

SIEMENS FENIX 1B (A)				
SIEMENS FENIX 1B (B)				
SIEMENS FENIX 1B (C)				
SIEMENS FENIX 1B (D)				
SIEMENS FENIX 1B (E)				
SIEMENS FENIX 1B (F - G)				
SIEMENS FENIX 1B (H)				
SIEMENS FENIX 1B (I)				
SIEMENS FENIX 3B (J)				
SIEMENS FENIX 3B (K)				
SIEMENS FENIX 3B (L)				
SIEMENS FENIX 3B (M)				
SIEMENS FENIX 3B (N)				
SIEMENS FENIX 5				
SIEMENS SAFIR				
SIEMENS SID 301 (CLIO III)				

Configurations

Air Conditioning

ECU replacement

EGR Adaptative

Erase Programmed Values
Pressure Regulation Adaptives
Programming Reinitialisation
Water in Diesel Information

Write of VIN

SIEMENS SIRIUS 32 (CLIO III)

Configurations

AC Air Heater Resistor Management

Air Conditioning

Downstream Oxygen Sensor
Erase Programmed Values

GearBox Type

Lock Injector Control

OBD Warning Lamp

Traction Control

Unlock Injector Control

Upstream Oxygen Sensor
Vehicle Speed Connection Type

Write of VIN

SIEMENS SIRIUS 32 E1

Configurations

AC Cold Loop in the Injection

Camshaft Offset

Downstream Oxygen Sensor
Electric Windshield Wiper
Fan Control, Engine Running
Fixed Displacement Compresor

Gear Box Type

Gear Change Warning Light
Injection <-> Air Conditioning Connections
Injection -> LPG connection
Learned Parameters Reset
OBD Fault Memory Erasing
Pencil Type Ignition Coil
Read Air Conditioning Configuration
Reduced Flow Fuel Pump
Thermoplunger Management
Upstream Oxygen Sensor
Vehicle Speed Connection Via The CAN

SIEMENS SIRIUS 32_RD420

Configurations

Climatization

Downstream Oxygen Sensor

GearBox Type

Idle Speed Decrease

Idle Speed Increase

Injection <-> Air Conditioning Connections
Learned Parameters Reset
Thermoplunger Management

Trajectory Control

Upstream Oxygen Sensor
Vehicle Speed Connection Type

Write of VIN

SIRIUS 34 E553

Configurations

AC -> Injection Connection Via The Can
AC Cold Loop in the Injection
Air Temperature Sensor Type A

Camshaft Offset

Downstream Oxygen Sensor
Fixed Displacement Compresor

GearBox Type

Learned Parameters Reset

OBD Light

Pencil Type Ignition Coil
Read Oxygen Sensor Option
Reduced Flow Fuel Pump

Thermoplunger Management
Upstream Oxygen Sensor
Vehicle Speed Connection Via The CAN

SIRIUS 34 E565				
SIRIUS E1 VDIAG 0C				

Configurations

Programming Reinitialisation

SIRIUS E1 VDIAG 10				

Configurations

AC Cold Loop in the Injection

Camshaft Offset

Downstream Oxygen Sensor
Electric Windshield Wiper
Fan Control, Engine Running
Fixed Displacement Compresor

Gear Box Type

Gear Change Warning Light
Injection <-> Air Conditioning Connections
Injection -> LPG connection
Learned Parameters Reset
Pencil Type Ignition Coil
Read Air Conditioning Configuration
Reduced Flow Fuel Pump
Thermoplunger Management
Upstream Oxygen Sensor
Vehicle Speed Connection Via The CAN

IMMOBILIZER

System	DTCs	Parameters	Actuators	Configurations
ANTIDEMARRAGE BII 3.9 (J66) ANT				

Configurations

Enter Access Code

Programming with 1 Key
Programming With 2 Keys

ANTI-THEFT BIFUNCTION X56				

Configurations

Diesel Engine Immobiliser
Diesel Petrol Engine Immobiliser Without Coded Solenoid Valve
Enter EMERGENCY CODE
Programming with 1 Key
Programming With 2 Keys
With Infra Red Remote Control
With Radio Frequency Remote Control
With Timed Courtesy Light
Without Timed Courtesy Light

ANTI-THEFT CRYPTO KEY				

Configurations

Diesel Engine Configuration

Enter Access Code

Petrol Engine Configuration

Type 1 Unit

Type 2 Unit

ANTI-THEFT KEY				

Configurations

After Market Repair Date
Diesel Engine Configuration
Enter EMERGENCY CODE
Petrol Engine Configuration

ANTI-THEFT TIR 96				
ANTI-THEFT TIR ISO 8				

Configurations

Automatic Start Up Type
Courtesy Light Extinguish Mode
ECU Programming with Immobilizer Warning Lamp
ECU Programming without Immobilizer Warning Lamp

Engine Type

Enter EMERGENCY CODE

Timer Courtesy Light

BMT (N1/N2)(N5/N6) (IMMO)				

Configurations

Calibration Finished

Coded Diesel Solenoid

Enter EMERGENCY CODE

Key Programming

UCH TRANSV 5_1 HDG (IMMO)

Configurations

Key programming

Program Body Computer

UCH x06 (IMMO)

Configurations

Key Programming

Program Body Computer

UCH x65 MEXIQUE (CLIO II)(IMMOBILISER)

Configurations

Key Programming

Serial Number of the Vehicle - VIN code

UCH X65 MEXIQUE HAUT DE GAMME (IMMO)

Configurations

Key programming

Program Body Computer

UCH X65_09 (IMMO)

Configurations

Key Programming

Program Body Computer

UCH X65_0D (ANT)

Configurations

Key Programming

Program Body Computer

UCH X83 ALARME(IMMO)

Configurations

Key Programming

Program Body Computer

UCH X83_04 (ANT)

Configurations

Key Programming

Program Body Computer

UCH_X76G2005_V3.0 (ANT)

Configurations

Key Programming

Program Body Computer

INTERCONNECTION UNIT

System	DTCs	Parameters	Actuators	Configurations
BMT (N1/N2)(N5/N6) (BIC) CLIO				

Configurations

Autolocking When Driving Function Prevention

Automatic Re-Locking

Central Door Locking Button
Configuration Interior Light Timer
Illuminated Hazard Lamps Upon Impact
Over-Speed Warning Function
Programming 2ª Plip Key
Raid Function Authorisation
RF Function Configuration

Running Lights

Variable front wiper intermittent (frequency) configuration

DECODER CONTROL UNIT (BMT)

Configurations

Autolocking When Driving Function Prevention
Central Door Locking Button
Configuration Interior Light Timer
Programming 2ª Plip Key
Raid Function Authorisation
RF Function Configuration

HABITACLE BII 3.9 (J66)

Configurations

ADAC

Air Conditioning Type

Airbag Type

Driving Type

Engine Type

Hazard Lamps Recall On TRF
Oil Level Displayed 20sec

Radio Display

Rear Screen Type

Tailgate Module

UCH TYPE

Vehicle Type

UCBIC - PASSENGER COMPARTMENT INTERCONNECTION UNIT

Configurations

Alarm Configuration

Cabriolet Type Vehicle

Calibrate

Calibration Complete

Country Configuration

Other Type of Vehicle

Programming - TIR Code Erase
Programming - TIR Code Learning
Programming Engine Type - Diesel with Codified Electrovalve
Programming Engine Type - Petrol or Direct Diesel Injection
Programming Immobilizer Function - Enable
Programming Immobilizer Function - Prohibition
Type 1 Engine Immobiliser Configuration
Type 2 Engine Immobiliser Configuration
Type 3 Engine Immobiliser Configuration
With Diesel Engine Immobiliser
With Headlight Washers
With Overspeed Warning

With Running Lights

With Timed Courtesy Light
Without Diesel Engine Immobiliser
Without Headlight Washers
Without Overspeed Warning

Without Running Lights

Without Timed Courtesy Light

UCH - PASSENGER COMPARTMENT CONTROL UNIT

Configurations

All Types Exept J64 4x4
Autolocking When Driving Function Prevention
Automatic Doors Lock Programming - Authorization
Automatic Doors Lock Programming - Disable

Cabriolet E64

ECU Programming with Immobilizer Type 1
ECU Programming with Immobilizer Type 2
Enter EMERGENCY CODE

J64 4x4

Keys Programming - Abandon Key Reallocation
Keys Programming - End of Key Reallocation Validation

Learning Blocking

Non Cabriolet E64

Programming Engine Type - Diesel with Codified Electrovalve
Programming Engine Type - Petrol or Direct Diesel Injection
Programming Immobilizer Function - Enable
Programming Immobilizer Function - Prohibition
Raid Function Authorisation

RF Function Authorised

RF Function Not Authorised

With Alarm

With Overspeed Warning

With Rear Wiper

With Rear Wiper Park

With Timed Courtesy Light

Without Alarm

Without Overspeed Warning

Without Rear Wiper

Without Rear Wiper Park
Without Timed Courtesy Light

UCH 83 (04)

Configurations

Automatic Locking

Automatic Locking

Clock

Course (Trajectory) Control System

Deadlocking

Engine Type

Instrument Panel Type

Original Equipment Alarm
Seat Belt not Fastened Buzzer

Second Fitting Alarm

Speed Index

Tachometer

Timer Courtesy Light

UCH Type

Vehicle Speed Information

Wiper Blade Inverted

Write of VIN

UCH J77-1002-44				
UCH TRANSV 5_1 (L90) HDG				

Configurations

Erase Computer Memory

Flashing Buzzer

Type N2

Type N2 (Specific To Russia)

Type N3

Type N4

Type N5

UCH Type

Write of VIN

UCH X06 X65 EXP Bas de Gamme (BIC)				
UCH X65 MEXIQUE				

Configurations

2 Button Radio Frequency Key

Automatic Relocking

Automatic Relocking

Bodywork type

Illuminate Hazard Lamps Upon Impact
Illuminate Hazard Lamps Upon Impact
Original Equipment Alarm
Raid Function Authorisation by Diag

Rear Screen Demister

Timer Courtesy Light

UCH Type

With Radiofrequency (RF) Function

UCH X65 MEXIQUE VDIAG 08				

Configurations

2 Button Radio Frequency Key

Automatic Re-Locking

Bodywork

Illuminated Hazard Lamps Upon Impact
Original Equipment Alarm
Raid Function Authorisation by Diag

Rear Screen Demister

RF Function Configuration

Timer Courtesy Light

Type Nº 2

Type Nº 3

UCH X65 VDIAG 5 (BIC)				

Configurations

Additional Wiping After Washing

Arabian Overspeed

Automatic Re-Locking

Daytime Running Lights

Headlamp Washer

Luminosity Sensor

Rain Sensor

Second Fitting Alarm

Timer Courtesy Light

UCH Type

Variable Windscreen Wiper Intermittent

UCH X65 VDIAG 9 (BIC)

Configurations

Additional Wiping After Washing

Arabian Overspeed

Automatic Re-Locking

Second Fitting Alarm

Timer Courtesy Light

UCH Type

Variable Windscreen Wiper Intermittent

UCH X85-0000-48

Configurations

New Vehicle Storage Mode Deactivation

Write of VIN

UCH-0012-09

Configurations

Aerial Test

Auto Locking Warning Sound
Automatic Closing of Windows (By Card)
Card Frequency (in MHz)

Card Locking

Card Type

Check Cards

Daytime Running Lights

Deadlocking

Driving Type

Electric Child Safety

External Follow Lighting

Following Tyre Change

GearBox Type

Hands Free Locking

Hands-Free Function

Hands-Free Start-Up

Hazard Warning Lights Illumination by ABS

Headlight Washers

Inhibition of Selective Door Opening

Light Sensor Sensitivity

Lights Automatic Illumination
Memorising Driver's Seat Position
Overspeed Function - Arabia

Rain/Light Sensor

Selective Opening of Doors

Sunroof

Type of Power Steering

Tyre Pressure Monitor Function

Vehicle Family

Vehicle Type

UCH-09-44

Configurations

Air Conditioning Type

Automatic Relocking

Automatic Relocking

Childproof Lock

Daytime Running Lights

Deadlocking

Driving Type

Engine Type

External Follow Lighting
External Follow Lighting

Front Fog Lamp

Front Fog Lamp

GearBox Type

Hands-Free Function

Hazard Warning Lights Illumination by ABS
Hazard Warning Lights Illumination by ABS

Heating Resistor Type

Illuminated Hazard Lamps Upon Impact

Light Sensor

Pax System Type Tyre

Rain Sensor

Rear Wiper Park Position Management
Selective Opening of Doors
Tyre Pressure Monitoring

Vehicle Type

Windscreen Type

UCH-90-04

Configurations

Arabian Overspeed

Auto Locking Warning Sound
Automatic Closing of Windows
Automatic Locking When Driving

Automatic Seat Recall

Automatic Transmission

Card Locking

Card Reminder Warning
Daytime Running Lights

Deadlocking

Doors Unlocked

Doors Unlocked in Hands Free Mode

Electric Child Safety

Emergency Braking Hazard Warning Lights
Enter Recommended Pressures
Erasing after tyre replacement

Hands Free

Hands Free Locking

Interior Light

Memorising Driver `s Seat Position

Model:

Power Steering

Programming Card

Rain Sensor

Roof Light Timmer Limitation
Serial Number of the Vehicle - VIN code

Set of Wheels selected

Steering Type Configuration
Tyre Pressure Monitoring

Voice Synthesizer

UCH-90-0C

Configurations

Arabian Overspeed

Arabian Overspeed

Auto Locking Warning Sound
Automatic Closing of Windows
Automatic Locking When Driving

Automatic Seat Recall

Card Locking

Card Reminder Warning
Daytime Running Lights

Deadlocking

Door Unlocking Mode

Driving Type

Electric Child Safety

External Follow Lighting

GearBox Type

Hands Free Locking

Hands-Free Function

Hazard Warning Lights Illumination by ABS

Interior Light

Lights Automatic Illumination
Memorising Driver `s Seat Position
Power Assisted Steering

Power Steering

Programming Card

Rain Sensor

Timer Courtesy Light

Tyre Pressure Monitoring
Tyre Pressure Monitoring
Unlocking Mode Doors Hands Free

Valve

Voice Synthesizer

UCH-B400-48				
UCH-B500-4D				

Configurations

Air Conditioning Type

Automatic Re-Locking

Childproof Lock

Daytime Running Lights

Deadlocking

Driving Type

Engine Type

External Follow Lighting
External temperature sensor circuit
Front Fog Lights Activation

GearBox Type

Hands Free

Hazard Warning Lights Illumination by ABS

Heating Resistor Type

Illuminated Hazard Lamps Upon Impact

Light Sensor

One Touch Electric Windows
Originally Fitted Permetric Protection

Pax System Type Tyre

Programming Card

Programming the Codes of the Four Valves

Rain Sensor

Rear Wiper Park Position Management
Selective Opening of Doors
Tyre Pressure Monitoring

Valet Card Function

Vehicle Type

Windscreen Type

UCH-J400-48				

PARKING ASSISTANCE

System	DTCs	Parameters	Actuators	Configurations
PARKING AID-0000-0C				

Configurations

Buzzer Volume

Front Buzzer Volume

Front Tone Setting

Tone Adjustment

Vehicle Identification

Write of VIN

PARKING ASSISTANCE -000-04				

Configurations

BUZZER VOLUME

BUZZER VOLUME

Tone Adjustment

Tone Adjustment

Vehicle Identification

Vehicle Identification

Write of VIN

PARKING ASSISTANCE x74 AAP				

Configurations

Buzzer Volume

Serial Number of the Vehicle - VIN code

Tono Adjustment

Vehicle Type

PARKING BRAKE

System	DTCs	Parameters	Actuators	Configurations
PARKING BRAKE B351-08				

Configurations

Save / Write Clutch Pedal Programming

Slope Initialisation

Vehicle Configuration

Write of VIN

PARKING BRAKE J84-B300-04				

Configurations

Computer Calibration And Operation

ECU replacement

Engine Type

GearBox Type

Slope Initialisation

Steering Wheel Position

Vehicle Configuration

Vehicle Configuration

Vehicle Type

Write of VIN

POWER STEERING

System	DTCs	Parameters	Actuators	Configurations
ELECTRIC PASS (CLIO III)				
ELECTRIC PASS (MODUS)				

Configurations

Steering Wheel Angle Sensor Programming
Write Date Of Last After Sales Operation

Write of VIN

POWER STEERING				

Configurations

Computer Calibration

PostSale Repair Date Modification
Steering Wheel Angle Sensor Programming

Write of VIN

POWER STEERING X56				
POWER STEERING X56 F2				

POWER STEERING X65 V 1.6				
Configurations				
After Market Repair Date				
Computer Calibration				
SUNROOF				
System	**DTCs**	**Parameters**	**Actuators**	**Configurations**
ELECTRIC ROOF COMPUTER UCT E84				
HOOD CONTROL X64				
TIRE PRESSURE CONTROL				
System	**DTCs**	**Parameters**	**Actuators**	**Configurations**
TIRE PRESSURE CONTROL M2S v9.0 X64 phase 3				
Configurations				
Erase Fault Codes				
Erasing after tyre replacement				
TYRE CONTROL SSPP J77-X85				
UPC				
System	**DTCs**	**Parameters**	**Actuators**	**Configurations**
UPC (CLIO III)				
Configurations				
Alternator type				
Engine Type				
UPC (MEGANE II)				
Configurations				
Alternator				
Alternator type				
Write of VIN				
UPC (MODUS)				