





















































































Application List - Opel / Version 9.5.0

Icons Legend

Existing Functionality    

Under Development 

Functionality does not apply 

ABS / ABR				
System	DTCs	Parameters	Actuators	Configurations
ABS BOSCH 2SE (+TC)				
ABS BOSCH 5 TC				
ABS BOSCH 5.3				
ABS BOSCH 5.3 / 5.4 (+TC) (ASTRA G/ ZAFIRA/ VECTRA B/ MERIVA) MY 1998				
ABS LUCAS 415				
ABS LUCAS EBC 430				
ABS TEVES MK60 (CAN) ASTRA H				
ABS/ETC 5.3-5.4 (+TC) (ASTRA G/ ZAFIRA) MY 1998				
ABS/ETC 5.3-5.4 (+TC) (Omega-B)				
ABS/ETC 5.3-5.4 (+TC) (Vectra-B)				
ABS/TC/ESP (ECU) ASTRA H MY 2004				
ABS/TC/ESP VECTRA C MY 2002				
AIRBAG (SRS)				
System	DTCs	Parameters	Actuators	Configurations
AIRBAG (CORSA-C/ MERIVA) MY 2001				
AIRBAG (SDM) (VECTRA C 2003/2006)				
AIRBAG (SMD) MRSZ TEMIC (ASTRA H 2004/2005)				
AIRBAG (SRS)				
AIRBAG S				
AIRBAG SAB6 (ASTRA G/ ZAFIRA) 1998-2000				
<i>Configurations</i>				
<i>Driver + Passenger</i>				
<i>Driver and Passenger Without Pretensioners</i>				
<i>Driver Only</i>				
<i>Driver Only Without Pretensioner</i>				
<i>Pretensioner Only</i>				
<i>Side Airbags</i>				
AIRBAG SAB8x (ASTRA G) MY 2000				
<i>Configurations</i>				
<i>Airbag Configuration</i>				
AIRBAG TEMIC 07 (CORSA-C/ MERIVA) MY 2001				
<i>Configurations</i>				
<i>Curtain Airbag</i>				
<i>Frontal Airbag</i>				
<i>Pretensioner</i>				
<i>Seat Occupied Detected</i>				
<i>Side Airbags</i>				
ANTI THEFT / IMMOBILIZER				
System	DTCs	Parameters	Actuators	Configurations
IMMOBILIZER				

















Configurations				
ERASE IGNITION KEY CODES IMMOBILIZER INITIALIZATION Program extra key				
IMMOBILIZER (S-10/ BLAZER) MY 2001				
Configurations				
ERASE IGNITION KEY CODES ERASE REMOTE CONTROL KEYS IMMOBILIZER INITIALIZATION Program extra key PROGRAM REMOTE CONTROL KEYS				
IMMOBILIZER II				
Configurations				
ENGINE ECU INITIALIZATION ERASE IGNITION KEY CODES IMMOBILIZER INITIALIZATION IMMOBILIZER RESET Program extra key RESET ECU				
ANTI-THEFT ALARM				
System	DTCs	Parameters	Actuators	Configurations
ANTI THEFT WARNING (S-10/ BLAZER)				
ANTI-THEFT ALARM (ZAFIRA) MY 2002				
Configurations				
ERASE REMOTE CONTROL KEYS PROGRAM REMOTE CONTROL KEYS				
ANTI-THEFT ALARM 90				
ANTI-THEFT ALARM 95 (CORSA-B)				
ANTI-THEFT ALARM 98 (ASTRA-G) 1999-2001				
Configurations				
ERASE REMOTE CONTROL KEYS PROGRAM REMOTE CONTROL KEYS				
ANTI-THEFT ALARM 98 (VECTRA-B)				
Configurations				
ERASE REMOTE CONTROL KEYS PROGRAM REMOTE CONTROL KEYS				
ANTITHEFT WARNING (CORSA C) 2004-2005				
AUTOMATIC GEARBOX				
System	DTCs	Parameters	Actuators	Configurations
AF 13 / 14 / 20				
AF 13-II / 17 / 20				
AF 13-II / 20 / 22 / 30				
AF 13-II/17/20/22 (ASTRA G) MY 1998				
AF 25 / 35				
AR 25 / 35				
BODY SYSTEM INTEGRATION				
System	DTCs	Parameters	Actuators	Configurations
BODY CONTROL MODULE (CORSA-C)				
Configurations				
ERASE REMOTE CONTROL KEYS PROGRAM REMOTE CONTROL KEYS				
BODY CONTROL MODULE (MERIVA) 2003-2005				
BODY CONTROL MODULE (VECTRA C 2002/2004))				
BODY CONTROL MODULE (VECTRA C 2005/2006)				
CENTRAL DOOR LOCK				
System	DTCs	Parameters	Actuators	Configurations
CENTRAL DOOR LOCK (ASTRA-G)				
Configurations				
ERASE REMOTE CONTROL KEYS PROGRAM REMOTE CONTROL KEYS				
CENTRAL DOOR LOCK (VECTRA-B)				
Configurations				
ERASE REMOTE CONTROL KEYS				

PROGRAM REMOTE CONTROL KEYS

CIM (STEERING COLUMN MODULE)				
System	DTCs	Parameters	Actuators	Configurations
CIM (STEERING COLUMN MODULE) ASTRA H 2004/2006				
DRIVER 'S DOOR MODULE				
System	DTCs	Parameters	Actuators	Configurations
DDM (DRIVER DOOR MODULE) VECTRA C				
ELECTRIC WINDOW WINDER				
System	DTCs	Parameters	Actuators	Configurations
ELECTRIC WINDOW WINDER (MERIVA) 2003-2005				
FRONT WINDOW WINDER (ASTRA G 1999-2005/ZAFIRA 2001-2005)				
ELECTRONIC DASHBOARD				
System	DTCs	Parameters	Actuators	Configurations
INSTRUMENT CLUSTER (ASTRA G/ZAFIRA) MY 1998				
<i>Configurations</i>				
<i>Instrument Service Reset</i>				
INSTRUMENT CLUSTER (CORSA-C/MERIVA) MY 2002				
<i>Configurations</i>				
<i>Instrument Service Reset</i>				
INSTRUMENT CLUSTER (S-10/ BLAZER) MY 2001				
INSTRUMENT CLUSTER (VECTRA)				
<i>Configurations</i>				
<i>Instrument Service Reset</i>				
IPC ECU(INSTRUMENT CONTROL UNIT)(ASTRA H 2004/2006)				
ENGINE COOLING MODULE				
System	DTCs	Parameters	Actuators	Configurations
ENGINE COOLING MODULE (ASTRA-G)				
ENGINE ELECTRONICS (PETROL/DIESEL)				
System	DTCs	Parameters	Actuators	Configurations
BOSCH DDE 2.1 (X 25 DT)				
BOSCH EDC 15 C7 (Z 17 DTL) (ASTRA G) MY 2003				
BOSCH EDC 15M (X 17 DTL)				
BOSCH EDC 15M (X 20 DTH)				
BOSCH EDC 15M (X 22 DTH)				
BOSCH EDC 15M (X 20 DTL) ASTRA G/ ZAFIRA				
BOSCH EDC 15M (Y 20 DTH) (ASTRA G/ ZAFIRA/ VECTRA B) MY 2000				
<i>Configurations</i>				
<i>VIN Code</i>				
BOSCH EDC 15M (Y 22 DTR)				
BOSCH EDC 16 C9 (Y 28 DTC) S-10				
BOSCH EDC16 (Z 17 DTH) ASTRA H MY 2004				
BOSCH EDC16 (Z 17 DTL) ASTRA H MY 2004				
BOSCH EDC16 (Z 19 DT) VECTRA C (FAP) MY 2005				
BOSCH EDC16 (Z 19 DT) VECTRA C MY 2007				
BOSCH PSG16 (Y 20 DTH) VECTRA C MY 2002				
BOSCH PSG16 (Y 22 DTR) VECTRA C MY 2003				
DEC 30 (Z 17 DTH) MERIVA MY 2004				
DELCO MT35E (Z16 XEP) ASTRA H				
DENSO V6 (Y 30 DT) VECTRA C 2003-2005				
ECOTRONIC				
EZ-PLUS				
HDRC (Y 17 DT) (ASTRA G) 2000-2003				
HDRC (Y 17 DT) (ASTRA G) MY 2004				
HDRC (Y 17 DT) (MERIVA) MY 2004				
HDRC (Y 17 DTL) (CORSA-C) 2001-2003				
HDRC (Y 17 DTL) (CORSA-C) MY 2004				
LOOEEA (Z 22 SE) (ZAFIRA) 2001-2005				
ME 1.5.5 (Z 12 XE) (CORSA C/ AGILA) MY 2001				

MOTOR 0100 (Z 22 SE) VECTRA C MY 2002				
MOTRONIC M 1.5				
MOTRONIC M 1.5.4 (C 20 NE)				
MOTRONIC M 1.5.4 (C 20 SE)				
MOTRONIC M 1.5.4 (C 20 SEL)				
MOTRONIC M 1.5.4 (C 20 XEV)				
MOTRONIC M 1.5.4 (C 22 NE)				
MOTRONIC M 1.5.4 (C 22 NE) Blazer				
MOTRONIC M 1.5.4 (C 22 SE)				
MOTRONIC M 1.5.5 (C 18 NE) ASTRA G 1999-2003				
MOTRONIC M 1.5.5 (C 18 YE)				
MOTRONIC M 1.5.5 (C 20 NE)				
MOTRONIC M 1.5.5 (C 20 SE)				
MOTRONIC M 1.5.5 (X 10 XE)				
MOTRONIC M 1.5.5 (X 12 XE)				
MOTRONIC M 1.5.5 (Z 10 XE) 2001-2003				
Configurations				
<i>BCM: Vehicle-ID is Programmed</i>				
<i>Immobilizer function programmed</i>				
<i>Instrument: Status of Vehicle-ID</i>				
<i>Instrument: Vehicle-ID is Programmed</i>				
<i>Security Wait Time</i>				
<i>Status of Vehicle_ID (Body Control Module)</i>				
MOTRONIC M 2.5 (C 20 XE)				
MOTRONIC M 2.7 (C 20 LET)				
MOTRONIC M 2.8 (C 20 XE)				
MOTRONIC M 2.8.1 (C 41 GE)				
MOTRONIC M 2.8.1 (X 25 XE)				
MOTRONIC M 2.8.3				
MOTRONIC ML 4.1				
MS 71 (Z 18 XE) (ASTRA G/ZAFIRA) MY 2001				
MS 71.5 (Z 18 XE) (VECTRA C) MY 2003				
MS 75 (Z 18 XER) ASTRA H MY 2006				
MSA 15 25 TDS (FRONTERA) MY 2007				
MULTEC (F)				
MULTEC (H)				
MULTEC (H) (C 10 NE) (SUZUKI FUN)				
Configurations				
<i>Immobilizer function programmed</i>				
<i>Security Wait Time</i>				
MULTEC (H) (C 14 NE) (CORSA-C) 2003-2005				
Configurations				
<i>BCM: Vehicle-ID is Programmed</i>				
<i>Immobilizer function programmed</i>				
<i>Instrument: Status of Vehicle-ID</i>				
<i>Instrument: Vehicle-ID is Programmed</i>				
<i>Security Wait Time</i>				
<i>Status of Vehicle_ID (Body Control Module)</i>				
MULTEC (H) (C 18 SEL) (MERIVA) 2003-2005				
MULTEC (H) (Z 14 XE / Z 16 XE) (ASTRA G) MY 2001				
Configurations				
<i>Immobiliser Function Programmed</i>				
<i>Security Wait Time</i>				
MULTEC (H) (Z 14 XE) (CORSA C) MY 2004				
Configurations				
<i>BCM: Status Vehicle-ID</i>				
<i>BCM: Vehicle-ID is Programmed</i>				
<i>Immobilizer function programmed</i>				
<i>Instrument: Status of Vehicle-ID</i>				
<i>Instrument: Vehicle-ID is Programmed</i>				
<i>Security Wait Time</i>				
MULTEC (H) (Z 16 XE) (MERIVA/ZAFIRA) MY 2003				

MULTEC (H) (Z 16 XE) VECTRA C MY 2002				
MULTEC (H) (Z 16 XEP) ASTRA G				
MULTEC (U)				
MULTEC ACG(M) (14 SE / 16 LZ 2)				
MULTEC ACG(M) (C 14 SE)				
MULTEC ACG(M) (C 16 SE)				
MULTEC H (C 18 NE) (CORSA-C) 2004-2005				
MULTEC IEFI				
MULTEC M - Corsa				
MULTEC M (B 22 NZ) (S-10/ BLAZER)				
MULTEC S				
MULTEC SX (X16XEL)				
MULTEC SZ (X 12 SZ)				
MULTIJET 602 (Z 13 DTH) (ASTRA H) MY 2006				
MULTIJET 6J0/ 602 (Z 13 DT) MERIVA MY 2006				
MULTIJET 6J0/602 (Z 13 DT) CORSA C MY 2004				
SIMTEC 56.0				
SIMTEC 56.1				
SIMTEC 56.5 (C 18 SEL)				
SIMTEC 56.5 (C 20 SEL)				
SIMTEC 56.5 (C 22 SEL)				
SIMTEC 56.5 (X 18 XE)				
SIMTEC 56.5 (X 20 XEV)				
SIMTEC MS 70 (X 18 XE1) ZAFIRA				
SIMTEC MS 70 (X 20 XEV)				
SIMTEC MS 71 (Y 22 XE)				
Configurations				
<i>Immobilizer function programmed</i>				
<i>Security Wait Time</i>				
SIMTEC MS 71 (Z 18 XE)				
SIMTEC MS 71 (Z 22 XE)				
Configurations				
<i>Immobilizer function programmed</i>				
ENTERTAINMENT HEAD UNIT (EHU)				
System	DTCs	Parameters	Actuators	Configurations
EHU (ENTERTAINMENT HEAD UNIT) ASTRA H 2004/2006				
MULTIFUNCTION DISPLAY / NAVIGATION				
System	DTCs	Parameters	Actuators	Configurations
DISPLAY BID DELTA (ASTRA-H)				
MULTIPLE INFORMATION DISPLAY (ZAFIRA) MY 1998				
TRIPLE INFORMATION DISPLAY				
TRIPLE INFORMATION DISPLAY (VECTRA-B)				
PASSENGER DOOR MODULE				
System	DTCs	Parameters	Actuators	Configurations
PDM (PASSENGER DOOR MODULE) Vectra C 2002/2006				
POWER STEERING				
System	DTCs	Parameters	Actuators	Configurations
EHPS (Electrohydraulic Power Steering) VECTRA C				
ELECTRONIC POWER STEERING (AGILA) MY 2000				
ELECTRONIC POWER STEERING (ASTRA G/ ZAFIRA) MY 2000				
ELECTRONIC POWER STEERING (CORSA-C) MY 2002				
ELECTRONIC POWER STEERING (MERIVA) MY 2003				
SERVOTRONIC				
RADIO				
System	DTCs	Parameters	Actuators	Configurations
RADIO CAR 300				

	RADIO CAR 400				
	RADIO CDR 500				
REAR ELECTRIC WINDOW WINDER					
	System	DTCs	Parameters	Actuators	Configurations
	REAR WINDOW WINDER (ASTRA G 1999-2005/ZAFIRA 2001-2005)				
REC (REAR ELECTRICAL CENTRE)					
	System	DTCs	Parameters	Actuators	Configurations
	REC (REAR ELECTRICAL CENTRE) ASTRA H 2004/2006				
UEC (UNDERHOOD ELECTRICAL CENTRE)					
	System	DTCs	Parameters	Actuators	Configurations
	UEC (ASTRA H 2004/2006)	